

User Manual

Manual del usuario



RECHARGEABLE LED CAMPING LANTERN

FAROL RECARGABLE
PARA ACAMPAR A LED



English....3

Español....7

Contents

| | |
|----------------------------|----|
| Contents..... | 4 |
| Charging | 5 |
| Safety | 6 |
| Warranty card | 11 |
| Warranty information | 12 |

CONTENTS


Wall adapter



On/Off switch
with adjustable
dimmer switch



Screw-off base
for easy storage
of charger and
adapter



Car charger

Charge Indicator Light
changes from red to
green when fully charged

Charging socket



USB cable

CHARGING

- Remove AC Adapter and/or Car Charger from the base of the lantern.
- Charge the lantern for 6-7 hours. The charge indicator light will change from red to green when charging is complete.
- Usage time after full charge is 5-10 hours, depending on brightness setting.
- Do not turn the lantern on while charging.
- Return charger to the inside of the base of lantern for easy storage.

**WARNING!**

- Please charge the battery before initial use.
- Do not turn on the unit when battery is low. If battery is low, turn lantern off.
- Do not charge the battery for more than 16 hours.
- Do not charge the battery in a confined space.
- Do not place the battery in or near a fire, on stoves, or near other high temperature locations.
- Do not attempt to disassemble the lantern for any reason.
- Do not switch between ON and OFF repeatedly within a short period of time. Pause for five seconds to avoid decreasing the LED lifetime.
- Store in a cool area with low humidity.
- When the product has not been used for two months or more, recharge the battery.
- Do not leave lantern outdoors in the rain.

Contenido

| | |
|---------------------------------|----|
| Contenido..... | 8 |
| Carga..... | 9 |
| Seguridad..... | 10 |
| Información de la garantía..... | 13 |
| Tarjeta de garantía..... | 14 |

CONTENIDO

Interruptor de encender/
apagar con regulador de
intensidad

Base que se
desenrosca
para facilitar el
almacenamiento
del cargador y el
adaptador



Cable USB



Toma para cargar

Adaptador de
pared



Cargador
de vehículo

Luz indicadora de carga
que cambia de rojo a
verde cuando está
completamente cargada

CARGA

- Extraer el adaptador de CA y/o cargador de vehículo de la base del farol.
- Cargar el farol durante 6-7 horas.
- El tiempo de uso después de la carga completa es de 5-10 horas, dependiendo del ajuste del brillo.
- Para mejorar la vida de la batería, no mantenga el farol encendido durante 10 horas continuas después que se ha cargado la batería por completo.
- No encender el farol mientras se carga.
- Regrese el cargador al interior de la base del farol para facilitar el almacenamiento.



¡ADVERTENCIA!

- Cargar la batería antes de usar.
- No encender la unidad cuando la batería está baja. Apague el farol si la batería está baja.
- No cargar la batería por más de 16 horas.
- No cargar la batería en un espacio confinado.
- No colocar la batería en o cerca de un fuego, sobre las estufas, o en las cercanías de otros lugares de alta temperatura.
- No intentar desarmar el farol por ninguna razón.
- No cambiar entre encendido y apagado repetidas veces en un corto período de tiempo. Haga un pausa de cinco segundos para evitar disminuir la vida útil de los LED.
- Almacenar en un área fresca con baja humedad.
- Recargar la batería si no se ha usado el producto durante dos meses o más.
- No dejar el farol al aire libre en la lluvia.



WARRANTY CARD

RECHARGEABLE LED CAMPING LANTERN

Your details: _____

Name: _____

Address: _____



_____ Email: _____

Date of purchase*: _____

* We recommend you keep your receipt with this warranty card.

Location of purchase: _____

Description of malfunction:



Return your completed warranty card
together with the faulty product to:

EuroCentra, Inc.
801 Circle Ave.
Forest Park, IL 60130
USA
service@eurocentra.net

AFTER SALES SUPPORT

52358



USA

866 558 8096

service@801service.net

05/2017

Hotline:
866-558-8096

Operating Hours:
Monday - Friday
10 AM - 6 PM EST

2

YEAR WARRANTY
AÑOS DE GARANTÍA

ALDI INC. FULL WARRANTY CONDITIONS

Dear Customer,

The **ALDI warranty** is a full warranty offering you the following benefits:

Warranty period: **2 years** from date of purchase with original, dated proof of purchase receipt.

Costs: Free replacement product or refund at EuroCentra's discretion.

| |
|---|
| <p>ADVICE: Please contact our service hotline by phone or e-mail should you need to make a claim or if you have a question regarding this product.</p> |
|---|

In order to make a claim under the warranty, please send us:

- The original receipt and the properly completed warranty card.
-

The warranty does not cover damage caused by:

Accident or unanticipated events (such as lightning, water, fire etc.).

Improper use or transport.

Disregard of safety and maintenance instructions.

Other **improper treatment or modification.**

Commercial use.

The warranty is non-transferable and applies only to the original purchase and does not apply to subsequent owners of the product. In no event shall liability exceed the purchase price paid by the purchaser of the product. Under no circumstances shall there be liability for any loss, loss of profits, direct, indirect, special or consequential damage arising out of, or in connection with use of this product.

This warranty is only valid in the United States. This warranty gives you specific legal rights. However, you may have other rights that vary from state to state. Some states do not allow limitation on implied warranties or exclusion of consequential damages therefore these restrictions may not apply to you. Due to constant product development and market changes, EuroCentra, Inc. can only guarantee that replacements will be available within the two-year warranty period.



TARJETA DE GARANTÍA

FAROL RECARGABLE PARA ACAMPAR A LED

Sus detalles: _____

Nombre: _____

Dirección: _____



Correo electrónico: _____

Fecha de compra*: _____

*Recomendamos guardar el recibo con esta tarjeta de garantía.

Lugar de compra: _____

Descripción del defecto:



Envíe la tarjeta de garantía rellena junto con el producto defectuoso a:

EuroCentra, Inc.
801 Circle Ave.
Forest Park, IL 60130
USA
service@eurocentra.net

SERVICIO POSVENTA

52358



USA

866 558 8096

service@801service.net

05/2017

Servicio al cliente:
866-558-8096

Horas de servicio:
Lunes a viernes
10:00 a.m. - 6:00 p.m., EST

2

YEAR WARRANTY
AÑOS DE GARANTÍA

CONDICIONES DE LA GARANTÍA COMPLETA DE ALDI INC.

Estimado cliente:

La **garantía Aldi** es una garantía completa que le ofrece los siguientes beneficios:

Período de garantía: 2 años a partir de la fecha de compra con recibo original fechado de prueba de la compra.

Costo: Reemplazo gratis del producto o reembolso a discreción de EuroCentra.

RECOMENDACIÓN: Póngase en contacto con nuestra línea directa de atención por teléfono o correo electrónico si necesita hacer una reclamación o tiene alguna pregunta acerca de este producto.

Para hacer una reclamación bajo la garantía, por favor envíenos:

- El recibo original y la tarjeta de garantía completada de manera apropiada.

La garantía no cubre a los daños ocasionados por:

Accidentes o eventos imprevistos (como rayos, agua, fuego, etc.).

Uso o transporte inadecuados.

Incumplimiento de las instrucciones de seguridad y mantenimiento

Otro **tratamiento o modificación inadecuados.**

Uso comercial.

La garantía no es transferible y es aplicable solamente al comprador original y no a los propietarios subsiguientes del producto. En ningún caso la responsabilidad excederá el precio de compra pagado por el comprador del producto. En ninguna circunstancia habrá responsabilidad por cualquier pérdida, pérdida de beneficios, daños directos, indirectos, especiales o consecuenciales, que surjan de o en relación con el uso de este producto.

Esta garantía solo es válida en los Estados Unidos. Esta garantía le otorga derechos legales específicos. Sin embargo, usted puede tener otros derechos que varían de estado a estado. Algunos estados no permiten la limitación en las garantías implícitas o la exclusión de los daños consecuenciales, por lo tanto estas limitaciones pueden no ser aplicables a usted. Debido al constante desarrollo de los productos y a los cambios del mercado, EuroCentra, Inc. solamente puede garantizar la disponibilidad de los reemplazos dentro del período de garantía de dos años.



DISTRIBUTED BY • DISTRIBUIDO POR:

ALDI INC., BATAVIA, IL 60510
WWW.ALDI.US

AFTER SALES SUPPORT •

SERVICIO POSVENTA

PRODUCT CODE: 52358



866 558 8096



service@801service.net

05/2017

2

**YEAR WARRANTY
AÑOS DE GARANTÍA**