GARDENLINE

5pc Patio Set User Guide

Now that you have purchased a Gardenline® product you can rest assured in the knowledge that as well as your 2 year parts guarrantee you have the added peace of mind of dedicated helplines and web support.

AFTER SALES SUPPORT

🕿 🚳 1877 579 1550 💻 info@westfieldoutdoors.com

MODEL: 44643

Contents

2	Introduction	Page 02
3	Parts List	Page 03
4	Getting Started	Page 04
5	Assembly Instructions	Page 05-08
6	Features	Page 09
7	Warranty	Page 10-12

Congratulations!

You have made an excellent choice with the purchase of this quality Gardenline[®] product. By doing so you now have the assurance and peace of mind which comes from purchasing a product that has been manufactured to the highest standards of performance and safety, supported by the high quality standards of Aldi. We want you to be completely satisfied with your purchase so this Gardenline[®] product is backed by a comprehensive manufactuer's 2 year warranty and an outstanding after sales service through our dedicated Helpline. We hope you will enjoy using your purchase for many years to come.

If you require technical support or in the unlikely event that your purchase is faulty please telephone our Helpline for immediate assistance. Faulty product claims made within the 2 year warranty period will be repaired or replaced free of charge provided that you have satisfactory proof of purchase (keep your receipt). This does not affect your statutory rights. However, be aware that the warranty will become null and void if the product is found to have been deliberately damaged, misused or disassembled.

Parts List

Parts List			
No.	Picture	Desctiption	Qty
A		Table Top	1
В		Table Leg	4
с		Lower Center Ring	1
D		Upper Center Ring	1
E		Screw(M6*55)	8
F		Washer	8
G		Nut	8
н	5	Wrench	1
I		Allen Key	1



Identify all the parts packaged in the carton against the parts list. Remove all protective materials and place parts on a nonabrasive surface to avoid scratching. If any parts are missing or damaged, DO NOT attempt to assemble. Please contact our customer service center (Mondy-Friday 9:00 am - 4:00 pm Est.) at 1-877-579-1550.

Caution

Read all the instructions before assembly. Failure to do so may result in faulty assembly and potential injury! Assemble product on a soft, non-abrasive surface such as a carpet or cardboard to avoid damaging the item. Seek assistance to assemble bulky or heavy items. After final alignments, make sure all bolts and nuts are securely tightened with screw covers pressed in place.


Warning

- 1. Do not crawl or stand on glass table top.
- 2. Do not set or lay heavy items on glass table top.
- 3. Avoid extreme hot and cold items being placed on glass table top
- 4. This glass table top is produced with tempered glass which is designed to safely shatter in small pieces when impacted or stressed beyond strength limitatons.

Assembly Intructions

FIG.1 B

1. Turn the Table Top (A) upside down and slide the legs (B) into the receiver on the table top. See Fig.1




2. Attach the Upper Center Ring (D) to the legs using one M6*55 screw (E), one washer (F) and one nut (G). Repeat this step to attach the other legs. Do not fasten at this time. See Fig.2

05

AFTER SALES SUPPORT

Assembly Instructions



3. Attach the Lower Center Ring (C) to the legs using one M6*55 screw (E), one washer (F) and one nut (G). Repeat this step to attach the other legs. Tighten all screws. See Fig.3



4. Turn the table upright . Now the table is ready for use. See Fig.4



AFTER SALES SUPPORT

Warranty

Two Year Limited Warranty

All furniture sold by Aldi is warranted to the original purchaser against defects in workmanship and materials. If a product sold by Aldi fails during the first two years from date of purchase under the terms of our limited warranty, please contact our customer service at: 1-877-579-1550. (Glass breakage is not warranted)

Note: You must retain original receipt to obtain warranty!

Frames

Frames are warranted against defects in materials and workmanship from the date of original purchase. Damage to frame or welds due to commercial use, improper assembly, exposure to water and sub-freezing temperatures and/or abuse are not covered.

Fabric

Sling fabric is warranted against separation at the seams. Fading, mildew, and/or discoloration due to exposure to elements, chemicals and spills are not covered.

The finish is warranted against blistering, peeling, or cracking. Fading resulting from exposure to elements, chemicals and spills are not covered. Scratches and chips due to normal wear and use are not covered.

Freight & Packing

Aldi will be responsible for shipping, handling and packaging charges for all valid warranty claims.

Care & Maintenace

Be careful to never allow water build up in frames as this will cause corrosion and freeze damage in cold climates. Wash all frames with a solution of mild soap and water. Rinse with clean water and dry with a soft absorbent cloth towel. Frames can be treated with a liquid wax for maximum protection against UV rays and/or salty damp air. Sling fabric may be cleaned by hand with a solution of mild soap and water with a clean water rinse.

Warranty

Exclusions

- Damage caused by acts of nature
- Wind damage
- Failure caused by unreasonable, unanticipated or abusive use
- Failure caused by a lack of reasonable and necessary care and maintenance
- \cdot Normal fade of fabrics, upholstery or woven materials
- Glass table top
- Bursting or cracking of tubing due to exposure to water and freezing temperatures
- \cdot Changes in wood color due to the natural aging of the wood
- · Lack of original receipt will void warranty

CUSTOMER SERVICE

Call Westfield customer service center

1-877-579-1550

Mondy-Friday 9:00 am - 4:00 pm Est. or Email: info@westfieldoutdoors.com (please include contact name, number, product style number and best time to contact) for all replacement parts and any questions you may have about this product!